



SWITCH POSITION	1	2	3
WOOFER DB DEOP	.4	0	0
MID-RANGE DB DEOP	.8	.6	.8
HIGH-RANGE DB DEOP	.3	.5	.7

WOOFER-----3903-2
 MID RANGE-----4500-2
 HIGH RANGE-----4600-2

CAPACITOR 12 mfd-----8115
 60 mfd-----8116
 72 mfd-----8084
 1000 mfd-----8117

COILS
 L1001 #4-----2739
 L1001 #10-----1238

RESISTOR 10 ohm 10w-----8114

EMBLEM-----2011
 GRILLE PANEL front-----2010
 side-----2008

GASKETS
 woofer-----0754E
 mid range-----0754F
 high range-----0754D
 woofers-----1429

SCREWS
 mid range-----738
 high range-----4724

SWITCH
 KNOB-----10841
 SWITCH BEZEL-----2019
 TRANSFORMER-----2018
 FUSE-----8118

AR